

Turret & Bullet Camera User Manual

UD.6L0201D1396A01

Thank you for purchasing our product. If there are any questions, or requests, please do not hesitate to contact the dealer.

This manual applies to

Type	Model
I	DS-2CE56C5T-IT1
	DS-2CE56C5T-IT3
II	DS-2CE16C5T-IT1
	DS-2CE16C5T-IT3
	DS-2CE16C5T-IT5

This manual may contain several technical incorrect places or printing errors, and the content is subject to change without notice. The updates will be added to the new version of this manual. We will readily improve or update the products or procedures described in the manual.

Please refer to the product specification for camera parameters and functions.

0100001040420

Regulatory Information

FCC Information

FCC compliance: This equipment has been tested and found to comply with the limits for a digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.


FCC Conditions


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

EU Conformity Statement

CE This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the Low Voltage Directive 2006/95/EC, the EMC Directive 2004/108/EC, the RoHS Directive 2011/65/EU.

 2012/19/EC (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info.

 2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union.

See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see: www.recyclethis.info.

1 Introduction

1.1 Product Features

This camera adopts new generation sensor with high sensitivity and advanced circuit board design technology. It possesses the features of high resolution, low distortion, and low noise, etc. It is extremely suitable for supervisory system and image processing system.

The main features are as follows:

- High performance CMOS sensor and high resolution bring high-quality image;
- Low illumination, 0.01 Lux @ (F1.2, AGC ON), 0 Lux with IR;
- Support IR cut filter with auto switch;
- OSD menu, parameters are configurable;
- Support auto white balance, auto gain control, electronic shutter control and internal synchronization;
- Advanced Engineering Design and patent universal adjustable structure provides convenient adjustment and high reliability;
- SMART IR mode;
- Unit transmission control;
- Advanced 3-axis design meets different installation requirements;
- Ingress protection: IP66.

1.2 Overview

1.2.1 Overview of Type I Camera




Figure 1-1 Overview of Type I Camera

1.2.2 Overview of Type II Camera




Figure 1-2 Overview of Type II Camera



The HD video output mode is set as the default. You can short the white and black line-end of the switch cable to switch the mode as CVBS output.

2 Installation

Before you start:

- Please make sure that the device in the package is in good condition and all the assembly parts are included.
- Make sure that all the related equipment is power-off during the installation.
- Check the specification of the products for the installation environment.
- Check whether the power supply is matched with your power output to avoid damage.
- Please make sure the wall is strong enough to withstand three times the weight of the camera and the mounting.
- If the wall is the cement wall, you need to insert expansion screws before you install the camera. If the wall is the wooden wall, you can use self-tapping screw to secure the camera.
- If the product does not function properly, please contact your dealer or the nearest service center. Do not disassemble the camera for repair or maintenance by yourself.

2.1 Installation of Type I Camera Steps:

1. Drill the screw holes and the cable hole on the ceiling according to the supplied drill template.




Figure 2-1 The Drill Template

2. Fix the mounting base to the ceiling with the supplied screws.




Figure 2-2 Fix the Mounting Base

- 3.Route the cables to the cable hole and connect corresponding power cable and video cable.
- 4.Secure the camera to the mounting base.
- 5.Fix the enclosure to camera.
- 6.Attach the trim ring to the camera and rotate it clockwise to secure the camera loosely.




Figure 2-3 Attach the Camera and Trim Ring

- 7.Adjust the surveillance angle according to the figure below.




Figure 2-4 3-axis Adjustment

- 8.Rotate the trim ring to get it fixed with the camera to complete the installation.




Figure 2-5 Complete the Installation

2.2 Installation of Type II Camera

Steps:

- 1.Drill the screw holes and the cable hole in the ceiling according to the supplied drill template.
- 2.Hammer the supplied plastic expansion bolt into the screw holes.




Figure 2-6 Drill Template

- 3.Route the cables to the cable hole and connect the corresponding cables.
- 4.Fix the camera to the ceiling with the supplied screws.




Figure 2-7 Fix the Camera to the Wall

5. Adjust the surveillance angle.

- 1). Loosen No.3 adjusting screw to adjust the pan position (0° ~ 360°).
- 2).Tighten No.3 adjusting screw.
- 3). Loosen No.2 adjusting screw to adjust the tilting position(0° ~ 90°).
- 4).Tighten No.2 adjusting screw.
- 5). Loosen No.1 adjusting screw to adjust the rotation position(0° ~ 360°) .
- 6).Tighten No.1 adjusting screw.




Figure 2-8 3-axis Adjustment

3 Menu Operation




Figure 3-1 Main Menu



A coaxial camera controller (purchase separately) is required to select the menu and adjust the camera parameters.

3.1 VIDEO.OUT

PAL or NTSC is selectable .

3.2 LANGUAGE

English and Chinese are selectable.

3.3SETUP

3.3.1 AE

Move the cursor to AE, and you can adjust the image brightness by the **BRIGHTNESS**, **AE MODE**, **AGC**, and **SENS-UP** in this menu.

As shown in Figure 3-2.

BRIGHTNESS : Set the brightness value from 1 to 10 to darken or brighten the image.

AE MODE: Set AE mode as **GLOBLE AE**, and **D-WDR**.

AGC: **HIGH**, **MIDDLE**, and **LOW** can be set for the AGC level. Select **OFF** to disable the AGC.

SENSE UP: Set the SENSE UP value as 0, 2, 4, 8, 10, 12, 14 and 16.

AE	
1. BRIGHTNESS	1- ---10
2. AE MODE	DWDR
3. AGC	OFF
4. SENSE UP	0- ---16
5. RETURN	↵

Figure 3-2 AE

MANUAL	
1. R GIAN	1- ---10
2. B GAIN	1- ---10
3. RETURN	↵

Figure 3-3 Manual of WB

3.3.2 WB

Move the cursor to WB, and you can set White Balance mode as **AUTO** and **MANUAL** in this menu.

AUTO: white balance is being adjusted automatically.

MANUAL: Set the **R GAIN/B GAIN** value from 1 to 10. As shown in Figure 3-3.

3.3.3 DAY & NIGHT

Move the cursor to DAY & NIGHT, and select **COLOR**, **B/W**, or **SMART** as the DAY & NIGHT mode.

COLOR: The image is colored in day mode all the time.

B/W: The image is black & white all the time, and the IR LED turns on in the low-light conditions.

SMART: Select to turn on/off the **INFRARED_LAMP** and to set the Smart IR level from 0 to 5. As shown in Figure 3-4.

3.3.4 Video Setting

Move the cursor to the VIDEO SETTING, and press the menu button to enter the video configuration interface. As shown in Figure 3-5.

CONTRAST: Set the CONTRAST value from 1 to 10.

SHARPNESS: Set the edge and detail sharpness value from 1 to 10.

COLOR GAIN: Set the color gain from 1 to 10.

3D NR: Set the 3D NR level as **High**, **Middle**, and **Low**. Select **OFF** to disable the 3D NR.

MIRROR: Set the mirror mode as **OFF**, **H**, **V**, or **HV**.

VIDEO SETTING	
1. CONTRAST	1- ---10
2. SHARPNESS	↵
3. COLOR GAIN	1- ---10
4. 3D NR	OFF
5. MIRROR	OFF
6. RETURN	↵

Figure 3-4 Video Settings

FUNCTION	
1. DETECTION	↵
2. MASKING	↵
3. ZOOM IN	50- ---100
4. LANGUAGE	ENGLISH
5. RETURN	↵

Figure 3-5 Function

3.3.5 FUNCTION

You can set **DETECTION**, **MASKING**, **ZOOM IN** and **LANGUAGE** of the camera in this menu. As shown in Figure 3-6.

DETECTION: Set the motion sensitivity as

WEAK, **LOW**, **MIDDLE** or **HIGH**. Select an **AREA** to enter the motion detection **AREA** menu. As shown in Figure 3-7.

AREA: Set the status as **OFF/ON**. Select a color for area border. Move the joystick up/down and right/left to set the horizon/vertical size and position.

As shown in Figure 3-8.

DETECTION	
1. SENSITIVITY	HIGH
2. AREA NO.0	↵
3. AREA NO.1	↵
4. AREA NO.2	↵
5. AREA NO.3	↵
6. RETURN	↵

Figure 3-6 Detection

AREA	
1. STATUS	OFF
2. COLOR	WHITE
3. HORIZON SIZE	0
4. VERTICAL SIZE	0
5. HORIZON MOVE	0
6. VERTICAL MOVE	0
7. RETURN	↵

Figure 3-7 Detection Area

MASKING: Select a masking back ground color. Select an **AREA** to enter the masking **AREA** menu.

As shown in figure 3-9.

AREA: Set the status as **OFF/ON**. Move the joystick up/down and right/left to set the horizon/vertical size and position.

As shown in Figure 3-10.

MASKING	
1. COLOR	WHITE
2. AREA NO.0	↵
3. AREA NO.1	↵
4. AREA NO.2	↵
5. AREA NO.3	↵
6. AREA NO.	↵
7. AREA NO.5	↵
8. AREA NO.6	↵
9. AREA NO.7	↵
10.RETURN	↵

Figure 3-8 Marsking Area

AREA	
1. STATUS	OFF
2. HORIZON SIZE	0
3. VERTICAL SIZE	0
4. HORIZON MOVE	0
5. VERTICAL MOVE	0
6. RETURN	↵

Figure 3-9 Masking

ZOOM IN: The ZOOM IN value can be adjusted from 50 to 100.

3.3.6 Reset

Reset all the settings to the default.

3.3.7 Save & Exit

Move the cursor to **SAVE & RESET**, and press OK to save the settings and exit the menu.